



TOP CLIP Installation tip: Tape carriage bolt head to interior of clip to aid installation.

1. Attach cross member
2. Fasten Diversimount to your wall at all four corners
3. Install bottom two clips
4. lift board into place, resting in bottom clips
5. Push top of board upward, flush with upright, install top clips and fasten

Needed, not supplied:
7/16 wrench, adjustable or socket
Wall fasteners

**Wall fasteners not included! Because of varied wall surface types, use a mounting fastener type you deem appropriate.*